



ATTACHING BIKR

REMOVE TOW ARM, TOW PLATE, & HEX WRENCH FROM PACKAGING

ATTACHING TOW PLATE TO COOLER

- 1 Use provided hex wrench to remove 4 hex bolts from logo plate
- 2 Remove logo plate
- 3 Place tow plate on side of cooler and ensure 4 holes align with tread points on cooler
- 4 Secure tow plate using same hex bolts from logo plate using hex wrench and ensure secure and free from any rattling
- 5 When towing the CampR, insert safety pin snugly into smaller hole and through tow hitch as shown. Store the safety pin in the same location on BikR plate when not in use.

INSTALLING TOW BAR

- 1 Remove or release left side of real axle bolt on bike tire (varies on make of bike)
- 2 Remove safety pin from spring side of tow bar
- 3 Remove anchor bolt from tow bar and place on left side of bike axle
- 4 Secure bolt or release back into original position on bike axle and ensure tow bar anchor bolt and bike tire is secure
- 5 Install anchor bolt back into tow bar and ensure safety pin is back in place
- 6 Insert square end of tow bar in female side on tow plate attached to cooler
- 7 Press down spring pin to clear tow plate wall and push tow bar into place until spring pin "clicks" in associated hole

ATTACHING BIKE DIAGRAM

ATTACHING TOW PLATE TO COOLER

— 1 & 2 —



— 3 —



— 4 —



— 5 —



INSTALLING TOW BAR

— 1 —



— 2 —



— 3 —



— 4 —



— 5 —



— 6 & 7 —

