



## GoPro Swivel Mount Instructions



- 1) Disassemble the mount—remove the small screws, remove the 3” screw and leave the black rubber washers.
- 2) Pull the camera mount out of the frame.
- 3) Remove the mount-frame mounting hardware at the bottom of the mount base.
- 4) Take the frame and position it on your helmet.
- 5) Mark the screw holes on the helmet.
- 6) Drill holes on the top of the helmet.
- 7) Mount the mount-frame on the helmet with the black rubber mounting.
- 8) Take your GoPro and put it onto the camera mount.
- 9) Take the 3” screw and slide it through the camera mount to check.
- 10) Reinstall the camera and mount into the frame.
- 11) Push the rubber washers so that they are butted-up against the camera mount.
- 12) Reinsert the 3” screw through the GoPro base until it is fully inserted.
- 13) Reinsert the 3/4” binding nut.
- 14) Tighten the screws into the binding nut so that there is enough friction to keep the camera from moving.
- 15) Find the camera angle that you want and tighten the mounting screw from both ends until there is little movement in the mount. It should be as tight as possible.

Note: when putting the mount with the camera in the mount-frame, you may have to slightly thread the 3” screw through the GoPro mount.

The supplied clear tape can be used if there is movement between the camera and the mount.