



5 Extension

2 Connector

1 Base

Instruction

- 1. Get out all parts with fittings and check them carefully.
- Find out "1 base" and "2 connector", fasten them firmly with "fasteners
 1".
- Pull out zinc pipe in "3 base upright", connect "3 base upright" to "1 base".
- 4. Screw the flower shape bolt and height adjust pin to "3 base upright", height adjust pin must be firmly screwed.



- 5. Connect the "4 crossbar" between zinc pipe, bolts them firmly.
- Insert the zinc post to "3 base upright", tighten all screws.
- Insert "5 extension" to "1 base", screw down the small blue slower shape bolts.
- 8. Connect all "5 extension" with "2 connector"
- 9. Check all bolts, connections, make sure thety are all deadly screwed.