



## Polaris RZR XP Turbo S Radius Rod Nut Retainer # S3161

### PARTS LIST

ITEM	PART #	DESCRIPTION	QTY
	S3161	Nut Retainer Plate (RH)	1
	S3161	Nut Retainer Plate (LH)	1
		M10-1.5x20mm Button Head Bolt	2
	30005-3	Nut Retainer Shim	2

### INSTALLATION

- 1.) Install Nut Retainer Plates onto front (transmission) side of rear frame.
- 2.) Capture OEM radius rod nuts into Nut Retainer Plates before mounting to frame.
- 3.) Slide 3005-3 shim over each M10-1.5x20 button head bolt.
- 4.) Thread each M10-1.5x20 button head bolt through frame from rear of vehicle, into threaded portion of Nut Retainer.
- 5.) Leave loose until all radius rods have been reinstalled.
- 6.) Tighten all hardware.



Polaris RZR XP Turbo S Radius Rod Nut Retainer # S3161





Polaris RZR XP Turbo S Radius Rod Nut Retainer # S3161

