

To install the DASH MOUNTED INDICATOR HARNESS:

- Mark the desired locations in the dash for the two LED dash mounted indicator lights.
- Drill two 9/32" mounting holes in the dash for the indicator lights.
- Carefully insert the LEDs into the grommet to prevent damage to the wires and resistor.

Hint: A little warmth and moisture help install the LED grommets.

- Seat the rubber grommet into the drilled hole, and then push the LED into the holder from the rear until it is slightly protruding.
- Connect the GREEN 3 pin connector of the DASH MOUNTED INDICATOR HARNESS, to the TURN SIGNAL/HORN SWITCH harness lead with BLUE color coding.