Hard Case requirements and recommendations

Interior at least 51/4" high, no longer than 24" in length

Pelican® 1400, 1450, 1500, 1550, 1600

Nanuk® 905, 915, 920, 925, 930, 940, 945

Plan the organization arrangement

Good organization starts with a good layout. Give careful thought to your layout before placing Edge-grips and cutting dividers.

Be sure to avoid surface features on the hard case interior that will prevent the Edgegrip from sitting flat.

Measure and mark out case with small marks.

Adhering the Edge-grip

Where edge-grip is to be located, wipe the hard case surface with Adhesion Promoter and let dry.

Peel off adhesion strip backing, press Edge-grip into place so that it sits just above the bottom radius of the case.

Cutting and Placing Correx® Dividers part1- Long lengths

Cut long length of Correx® divider first. Be aware of hard case taper.

Use a good pair of scissors or a razor blade and straight edge to cut divider.

Slide Pylons onto bottom edge divider approximately where they are to be located.

Slide divider with pylons down into the Edge-grip until the bottom of the pylons sit flat on the hard case bottom.

Cutting and Placing Correx® Dividers part2- Short lengths

Align pylons to their Edge-grip counterparts

Cut short divider pieces to fit in between edge-grip and pylons. Again, mind the taper.

Hard Case Organizer

Slide into place and ensure the short divider lengths do not push pylons and long lengths out of alignment.

Cut final short lengths of Correx® to go between pylons. Slide into place.

If a pylon does not connect to a 4^{th} divider of Correx® (for a long compartment), cut a $\frac{1}{2}$ inch strip to fit into the 4^{th} slot of the pylon. This ensures proper grip on the other 3 dividers.

Cap the pylons

Screw caps onto pylons

Organizer Kit Contents

