



Steps to Mod Podge Glitter tumbler

This is written for a one color tumbler

Items needed:

- Tumbler - make sure it is clean of oils and dirt.
- Spray paint – choose a paint as close to your glitter color as possible
- Glitter – I recommend starting with fine or ultra fine glitter
- Something to catch the extra glitter in (I use scrapbook paper)
- Mod Podge
- Disposable cup – to pour the mod podge in
- Spray Sealer
- Foam paint brush
- Bristle paint brush
- Epoxy (make sure it is clear when cured and FDA compliant)
- Turning method (either hand turn or turner)
- Gloves

Steps

- Spray paint the tumbler and allow to dry
 - Brush on a good coat of Mod Podge, you want it fully coated and you do not want to brush strokes
1. Sprinkle on the glitter, try to get full coverage (reminder to have something under the glitter to catch the extra)
- Let it sit and dry for at least 30 minutes (I leave mine sitting on a water bottle upside down, so the outside of the cup is not touching anything)
 - Tap the tumbler to remove excess glitter then Brush off extra glitter with a paint brush (do this in gentle strokes)
 - Spray the tumbler with sealer and let dry
 - Repeat steps 2-6 until you have good coverage and are happy with the look of the tumbler.
 - Allow to dry fully
 - Wipe of the rim of the cup and inside as needed
 - Epoxy the tumbler

Optional Steps:

- Add vinyl or waterslide
- Re-epoxy as needed

For more information or guides checkout us out at www.qmcreations.com