



JOBO International GmbH • Kölner Str. 58a • 51645 Gummersbach • Germany

JOBO Drum Super8 / 16mm # 3018 / 3016

Quick Start Guide



Please fix one end of the film to the film spool as illustrated below



The film must be wound around the spool quite tightly. It is important that the film does not leave the track of the reel to avoid overlapping parts of film. This is important to avoid underdeveloped film sections.

JOBO International GmbH • Kölner Str. 58a • D-51645 Gummersbach • Tel. +49 (0)2261 / 545-0 • Fax +49 (0)2261 / 545-22 • Mail: i_info@jobo.com • Internet: www.jobo.com
Sitz der Gesellschaft: Gummersbach. Eingetragen unter HRB 69080 beim Amtsgericht Köln. Geschäftsführer: Johannes Bockemühl-Simon.

ILN 40 22124 000007
USt-IdNr.: DE815 174 234
St.-Nr. 212/5720/0814

Deutsche Bank (BLZ 384 700 24) 0 22 64 15 00
IBAN: DE 65 384 700 24 00 22 64 15 00
SWIFT/BIC: DEUTDEDB384

Kreissparkasse Köln (BLZ 370 502 99) 3 41 55 50 36
IBAN: DE 61 370 502 99 03 41 55 50 36
SWIFT/BIC: COKSDE33

The other end of the film should be bent right underneath the rubber band as illustrated below:



Please avoid covering any larger amount of film with the rubber band to avoid underexposure of film sections!

For opening the Expert Super 8 / 16mm drum after processing we strongly recommend the use of our foot pump #3360.

Minimum fill amount: 330ml

All other fill amount of chemistry should be calculated according to the chemistry manufacturer.