

# Assembly Instructions

## Anti-Sway Stabilizer for UFS Projection Screen by Draper

### **Caution**

- ① Read instructions through completely before proceeding; retain for future reference.
- ② When attaching Anti-Sway Stabilizers to frame and legs, take care to avoid rocking the screen and causing it to fall.
- ③ Handle with care; do not allow Anti-Sway Stabilizers or Leg Clamps to come into contact with the viewing surface; this could rip the fabric.
- ④ Make sure Leg Clamps are completely hand tightened.

### **Leg Assembly**

- ① Attach optional Anti-Sway Stabilizers to inside of legs and bottom of frame using included leg clamps.
- ② Anti-Sway Stabilizers can be adjusted so they are further up or down the legs. Place and adjust so that the Anti-Sway Stabilizers avoid snaps and hinges.
- ③ Make sure Leg Clamps are completely hand tightened.



# DRAPER®

411 S. Pearl St., Spiceland, IN 47385 USA ■ 765-987-7999  
www.draperinc.com ■ fax 765-987-7142  
Copyright © 2014 Draper Inc. Form UFS-Anti-Sway\_Inst14 Printed in U.S.A.

*If you encounter any difficulties installing your Anti-Sway Stabilizer Bars, call your dealer or Draper, Inc. in Spiceland, Indiana, 765-987-7999, or fax 765-987-7142.*