



4" Recessed Trim

INSTALLATION INSTRUCTIONS



WARNING : These products may represent a possible shock or fire hazard if improperly installed or attached in any way. Products should be installed in accordance with these instructions, current electrical codes and/or the current National Electric code (NEC).

CAUTION - To reduce risk of re, electric shock or injury to persons :
Make sure that the electrical power to the fixture is disconnected prior to any installation or retrofit.

RECESSED TRIM INSTALLATION:

1. There are three different ways to install a recessed trim, based on the type:
 1. Bulb must be installed before the trim.
 2. Trim must be installed before the bulb.
 3. Bulb must be inserted into the trim, then installed.
2. Recessed 4" trims use tension clips to hold the trim within the housing.

