

ARCHITECTURAL LED TROFFER

INSTALLATION INSTRUCTIONS

MODELS: T3A-14-S-MV-35 T3A-22-S-MV-35 T3A-24-S-MV-35 T3A-14-S-MV-40 T3A-22-S-MV-40 T3A-24-S-MV-40 T3A-14-S-MV-50 T3A-22-S-MV-50 T3A-24-S-MV-50

The installation must only be performed by a licensed electrician.

To prevent death, injury or damage to property, this product must be installed in accordance to National Electrical Code (NFPA70) in the US or Canadian Electrical Code (CSA 22.1) in Canada.

Disconnect power before installing the product or servicing it.

Wait until fixture has cooled down before installing or servicing the fixture.

MIN. 90°C SUPPLY CONDUCTORS



- 2 Locate desired positioning for the fixture in ceiling grid.
- 3 Turn off power to appropriate circuit at the breaker box.
- 4 Place the fixture into the T-bar ceiling panel. Secure to structure and/or grid per state and local codes.
- 5 Remove cover from Power Supply/Junction Box by removing two screws. **NOTE**: Make sure to remove cardboard padding located between junction box and fixture housing.
- 6 Connect wiring as shown. Grey and Purple wiring are for 0 10V dimming systems. Cap off individually if not used.
 - Reattach cover of Junction Box and secure with two screws.
 - Turn power on and verify that the panel is lit.

8



