



## ERICA PARK BENCH

## You will need:

- Rubber Mallet.
- Allen Key provided in fixings bag.
- Screwdriver with torque head fitting
- 1. Open packaging, lay out pieces and check that the fittings bag is complete.
- 2. Partly tap the leg/arm assemblies onto the backrest part making sure that the holes in the backrest are pointing downwards towards the floor.
- 3. Offer up the seat part to the leg/arm assemblies and tap into position. If the mortices are tight then tap the leg/arm assemblies on to the seat part from different parts of the leg/arm assemblies in rotation.
- 4. Turn the assembled part so that it is upside down standing on the top of the leg/arm

- assemblies. Place some of the bubble wrap under for protection. Rest the arm part on a stool, box or something similar.
- 5. Place the screw caps in the four holes in the backrest and the two holes in the underneath of the seat part so that they are aligned to receive the threaded bars. Insert the threaded bars and using the allen key provided tighten onto the screw caps. If necessary use a screwdriver to wiggle the screw caps until they connect to the threaded bars. Tighten all the bars up firmly.
- 6. Screw in the four screws to the underside of the seat part connecting it to the leg/arm assemblies.



DON'T FORGET TO PAINT ON THE FURNITURE PROTECTOR AS SOON AS THE PRODUCT IS ASSEMBLED, UNLESS ANOTHER FINISH IS TO BE APPLIED.