



Overland Custom Design

www.overlandcustomdesign.com

WHAT TO EXPECT IN YOUR BOX

The items listed below are what you should see in your box.

Relocation Kit 10-UP FJ/Toyota 4runner

- Sway Bar Relocation Bracket - @2
- Round Spacer - @6
- M10 x 1.25 x 25MM SHCS - @4
- M10 x 1.25 x 40MM HCS - @6
- M10 Flat Washer - @6
- 3/8-16 x .75 HCS - @4
- 3/8 Flat Washer - @4
- M10 Oversized Flat Washer - @6

INSTALLATION OF SWAY BAR RELOCATION KIT

Scan the barcode for extended detail (pics and stuff) on how to install your kit. (coming soon)



- Place the vehicle on flat and level ground, then chock the rear tires.
- Remove OEM or aftermarket skid plates.
- Remove the radiator support brackets (3 bolts each side using a 14mm socket).
- Using two round spacers at each end and one round spacer in the center hole. Paired with 1 M10 oversized washer per spacer. Re-install the radiator support brackets, and torque to 35ft/lb.
- Disconnect the sway bar from the frame on both sides of the vehicle and remove the bracket from the sway bar (2 bolts per side using a 14mm socket).
- Install the relocation blocks with the supplied M10 x 25mm SHCS. Tighten using an 8mm allen wrench, and torque to 35ft/lb. Make sure threaded holes are toward the front of the vehicle.

- Install the OEM sway bar brackets to the relocation spacers using the supplied 3/8 x .75 HCS and 3/8 flat washers. Once all four bolts are installed torque to 35ft/lb.