



B106 303 Rolie Side Base Mounting Instructions

Thank You for your purchase!

****Please read and understand these instructions before touching your bike. ****

A properly mounted B106 303 Rolie Side Base and Tincup Pocket. Fig.1



Fig.1

1. Thread the 303 Rolie Side strap through the metal buckle then through the slot on the Base. Fig.2



Fig.2

2. Thread the webbing back through the buckle on the Rolie bag. Tighten securely. Tuck any excess webbing back through the slot on the base.

If you have any questions or need assistance please call us at: (800) 535-8131 Or email us at info@wolfmanluggage.com
Happy Riding. Woofle