



A

STANDARD FIXING

Most weather louvres are supplied with no fixings. In this instance we recommend drilling through either the louvre flange or the neck, and screwing directly into the supporting structure with an appropriate fixing.



B

PRE-DRILLED FACE FIXING HOLES

5mm fixing holes (not countersunk) will be drilled into the louvre frame before powder coating, allowing quick and easy fitting on site. Number and layout of fixing holes will be appropriate to louvre size.