



ez•connector

# T-Connector Install

The easiest way to connect the EZ Connector to your Ford or GM truck. A quick snap connection leaves you with both style plugs wired in parallel.

Tuck wires up and secure with provided cable tie. Mount bracket and attach the EZ Connector Socket.

Snap T-Connector into the back of the 7-way socket.

Snap the T-Connector into the wiring harness.

Insert a screwdriver to unsnap the wiring harness from the back of the 7-way socket.

