

You must install the tension bands on first and last bow prior to installing the wirelock base for your endwall/sidewall pipe. Use a tek screw through the tension band into the bow to keep the tension band from slipping. The tek screw MUST go on the inside of the greenhouse to avoid damaging your film.

