



## ASSEMBLY/INSTALL INSTRUCTIONS

### **Can-Am X3 Billet Bonnet Grille PART #: C-110A, C-110A-B, C-110A-BLK**

Your package should come with the following:

- (1) Stainless grille frame with installed billet pieces
- (2) ¼-20 Button Socket Cap
- (2) ¼-20 Nylock Nuts

Tools/Hardware Needed:

- 5/32 Allen
- 7/16 Socket
- Ratchet
- Drill
- ¼" Drill bit

Install Instructions:

Installing new bonnet grille:

1. Remove the top scoop by carefully pulling up.
2. Hold your bonnet grille frame in place on your plastic scoop and mark where you want to drill.
3. Drill through the plastic scoop in the desired position/markings.
4. Assemble the bonnet grille onto your scoop by fastening the socket cap screw and the nylock nut.
5. Carefully snap your top plastic scoop back into place one corner at a time.

**Congratulations! You have successfully completed your Tatum UTV upgrade! We cannot wait to see your build on Instagram & Facebook. Follow and tag us @TatumUTV.**

*If you have any questions or concerns with your order, please email [sales@tatumutv.com](mailto:sales@tatumutv.com).*

