



ASSEMBLY/INSTALL INSTRUCTIONS

Can-Am X3 Billet Grille

PART #: C-100A, C-100A-B, C-100A-BLK, C-100A-G

Your package should come with the following:

- (1) Billet grille assembled with mounting tabs
- (6) Socket head cap screws
- (2) Nylock nuts
- (6) Washers
- (4) Lock washers

Tools/Hardware Needed:

- 3/16 Allen
- 7/16 Wrench
- Ratchet
- 8mm wrench
- T20 (optional)
- T30 (optional)

Install Instructions:

Uninstalling factory grille:

1. Remove the top scoop by carefully pulling up.
2. Remove the factory grille by unscrewing the 2 screws holding the grille in place. Then, apply pressure to release the push-clips. The grille will push out through the front of the car.

Installing new grille:

3. Install the middle of the grille on the car (top & bottom) using 2 bolts, 2 regular washers and 2 nylock nuts from the hardware bag provided.
4. Install the corners using the remaining bolts, washers and lock washers from the hardware bag provided. The flat washer will press up against the plastics and the lock washer will press up against the socket head cap screw. *(If you need more space to work with, you may need to remove the front clip.)*

Congratulations! You have successfully completed your Tatum UTV upgrade! We cannot wait to see your build on Instagram & Facebook. Follow and tag us @TatumUTV.

If you have any questions or concerns with your order, please email sales@tatumutv.com.

