



ASSEMBLY/INSTALL INSTRUCTIONS

Can-Am X3 Sway Bar Links PART #: C-111S, C-111S-B

Your package should come with the following:

- (2) Sway bar links installed with spacers
- (8) Spacers
 - (8) U-102H
- (2) Bolts

Tools/Hardware Needed:

- 18mm socket
- 18mm wrench
- Impact
- Tape Measure
- 9/16 wrench
- 15/16 wrench

Install Instructions:

Uninstalling the old sway bar links:

1. Using the 18mm socket and 18mm wrench, loosen the lower and upper bolts on the sway bar links.
2. Set the old hardware to the side – we will be using those later.

Installing new sway bar links:

3. Remove the zip tie from the spacers.
4. Start by assembling the sway bar link into the rear trailing arm. Use the factory bolt to hold the lower end of the sway bar in place.
5. Next, assemble the upper end of the sway bar link into the sway bar. You will be using the bolt from the hardware bag paired with the factory nut.
6. Fasten all hardware.
7. Tighten the jam nuts by holding the heim in place with the 9/16 wrench while tightening the jam nut with the 15/16 wrench.

Congratulations! You have successfully completed your Tatum UTV upgrade! We cannot wait to see your build on Instagram & Facebook. Follow and tag us @TatumUTV.

If you have any questions or concerns with your order, please email sales@tatumutv.com.