



ASSEMBLY/INSTALL INSTRUCTIONS

RZR XP Turbo S Rear Sway Bar Links PART #: P-110S, P-110S-B

Your package should come with the following:

- (2) Sway bar links installed with spacers
- (8) U-102H Spacers

Tools/Hardware Needed:

- 19mm socket
- 19mm wrench
- Impact

Install Instructions:

Uninstalling the old sway bar links:

1. Using the 19mm socket and 19mm wrench, loosen the lower and upper bolts on the sway bar links.
2. Set the old hardware to the side – we will be using those later.

Installing new sway bar links:

3. Remove the zip tie from the spacers.
4. Use the factory bolt to hold the lower end of the sway bar in place.
5. Use the factory bolt to hold the upper end of the sway bar in place.
6. Fasten all hardware.

Congratulations! You have successfully completed your Tatum UTV upgrade! We cannot wait to see your build on Instagram & Facebook. Follow and tag us @TatumUTV.

If you have any questions or concerns with your order, please email sales@tatumutv.com.

P-110S

(2) U-102H



(2) U-102H



(2) U-102H



(2) U-102H

