

Step-by-Step Directions

1. Create sublimation design for desired blank.
2. If using a cutting machine see Artesprix Heat Resistant Transfer Mask Cutting Directions document.
If "fussy cutting" cut mask using scissors. Do not remove clear film before cutting.
3. Remove clear film from back of cut design.
4. Place cut design on blank, adhesive side down as desired.
5. Apply finished sublimation design to blank with adhered resistant mask shape using heat tape.
6. Transfer according to the sublimation specifications of the blank.
7. Carefully reveal design after transfer.



Things to remember:

- Where the mask was placed on the sublimation blank, the finished design will be the original color of the blank.
- Sublimation Blanks that are non-completely flat surface may allow ink to seep through which will achieve a muted look where the mask was placed.
- If you are using the mask to add text, your adhered mask should not be mirrored.
- Electric die cutting machines are also a great tool for cutting desired shapes.