

Tools You Will Need:

- Artesprix® Iron-on-Ink
- Artesprix® Blank Maple Bag Tag
- Plain Copy Paper
- Artesprix® Heat Tape
- Artesprix® Protective Paper
- Heat Source: Artesprix® Heat Press, Dry Iron, or Home Iron
- Artesprix® Project Mat

1. Using the Artesprix® Iron-on-Ink, apply your design to plain copy paper. Don't worry if the color looks dull, it will come to life when the heat is applied.

Note: While applying your design to copy paper, protect your work surfaces from potential ink bleed by placing an additional sheet(s) of copy paper underneath the original.

2. If using an Artesprix® Heat Press, set your temperature to 400° F. For a Dry Iron, set to linen or highest setting. For a Home Iron, set to linen or highest setting, and "No Steam".

Note: The holes in your home iron do not allow heat to pass through evenly.

3. Secure your design (face-down) to one side of your Artesprix® Maple Bag Tag with Artesprix® Heat Tape. *Note: Only use Artesprix™ Heat Tape on the outer edge of your design, not over it, as the heat resistant characteristic of the tape will affect the consistency of the transfer.*

4. Create a "Sublimation Sandwich", from bottom to top:

1. Artesprix® Protective Paper
2. Artesprix® Maple Bag Tag with design secured (face-down) on top
3. Artesprix® Protective Paper

Note: If using a Home Iron/Dry Iron you will want to use an Artesprix® Project Mat to absorb heat, protect your craft table, and ensure even pressure.

5. Set your Artesprix® heat press timer for 60 seconds and press. If using a Home Iron/Dry Iron, place "Sublimation Sandwich" on your Artesprix® Project Mat and hold stationary while pressing firmly for approximately 3 minutes.

Note: DO NOT leave Heat Source unattended.

6. Gently remove the paper from the blank to reveal your unique vivid design!
7. Attach Bag Tag Loop.
8. Do not forget to turn your Heat Source off.

