

Supplies

- Artesprix Iron-on-Ink™
- Blank Sequin Pillow Case
- Plain Copy Paper
- Heat Tape
- Protective Paper
- Heat Source: Craft Press or Heat Press
- Project Mat (if using handheld Heat Source)



BLANK	TIME (Seconds)	TEMPERATURE
Sequin Pillow Case	60	400°F

Directions

1. Measure a desired area on the Sequin Pillow Case and replicate the area as a template on Plain Copy Paper with a pencil. Combine 2 pieces of paper to create a larger template if needed.
2. Use Artesprix Iron-on-Ink to create the design. Keep in mind any text will need to be mirrored.
3. Flip all sequins white side up.
4. Place the design onto the white sequins and secure with Heat Tape.
5. Create a "Sublimation Sandwich." Cut two pieces of Protective Paper the size of the blank. Place one piece under the blank, and the other on top of the design.
6. Transfer the design at 400°F for 60 seconds.
7. Carefully remove the design from the Sequin Pillow Case.
8. Add standard 16" x 16" pillow insert.

Pro Tips:

- Before transfer, ensure the project is positioned so the heat only has to go through the paper to dye the blank.
- After transfer, before removing tape and the design, confirm the transfer is bright and vivid. If it is not, check the transfer time, temperature, pressure, and how the project is positioned, and re-press.