

Tools You Will Need

- Paint Brushes
- Water
- Non-porous surface to mix your paint on
- Artesprix Color Mixing Chart



Directions

1. Start by shaking the sublimation acrylic paint bottles to ensure a homogenous mixture.
2. Mix the colors you would like to use on a non-porous surface.
3. Paint on plain paper. Keep in mind any text will need to be mirrored.
4. Allow paint to dry on paper before transfer.
5. Transfer according to the specifications associated with your sublimation blank, different sublimation materials require different transfer time, temperatures, and pressure settings. Refer to Artesprix blank instructions for transfer specifications.
6. Clean brushes with soap and water.

Pro Tips:

- A little sublimation paint goes a long way.
- A Heat Gun or Hair Dryer may be used to speed up the drying process.
- Artesprix Sublimation Acrylic paint is designed to be mixed.
- White Acrylic Lighting Medium for Sublimation will not transfer. Use this in conjunction with the other four colors to create any color.

Color	Before Transfer	After Transfer
Red		
Yellow		
Blue		
Black		



Red



Hot Pink
Red : White
1 : 10



Bubble Gum
True Red : White
1 : 10



True Red
Red : Brown
10 : 1



Burnt Orange
Red : Yellow
1 : 2



Orange
Red : Yellow
1 : 10



Tangerine
Red : Yellow
1 : 20



Sunshine
Orange : White
1 : 10



Yellow



Green
Yellow : Blue
1 : 1



Lime
Yellow : Blue
10 : 1



Chartreuse
Lime : White
2 : 5



Emerald
Yellow : Blue
1 : 5



Sea Glass
Emerald : White
1 : 5



Blue



Pool
Blue : White
1 : 5



Royal
Blue : Red
5 : 2



Cornflower
Royal : White
1 : 5



Purple
Blue : Red
1 : 1



Violet
Purple : White
1 : 5



Brown
Purple : Yellow
1 : 1



Black



Gray
Black : White
1 : 10