

Supplies

- Artesprix Iron-on-Ink™
- Blank Wine Bag
- Plain Copy Paper
- Heat Tape
- Protective Paper
- Heat Source: Craft Press or Heat Press
- Project Mat (if using handheld Heat Source)



BLANK	TIME (Seconds)	TEMPERATURE
Wine Bag	60	400°F

Directions

1. Measure a desired area on the Wine Bag and replicate the area as a template on Plain Copy Paper with a pencil.
2. Use Artesprix Iron-on-Ink to create the design. Keep in mind any text will need to be mirrored.
3. Place the design onto the blank and secure with Heat Tape.
4. Create a "Sublimation Sandwich." Cut three pieces of Protective Paper the size of the blank. Place one piece under the blank, one on top of the design, and one inside the blank.
5. Transfer the design at 400°F for 60 seconds.
6. Carefully remove the design from the Wine Bag.

Pro Tips:

- Lint roll and pre-press fabric material before securing the design.
- Before transfer, ensure the project is positioned so the heat only has to go through the paper to dye the blank.
- After transfer, before removing tape and the design, confirm the transfer is bright and vivid. If it is not, check the transfer time, temperature, pressure, and how the project is positioned, and re-press.
- Allow blank to cool before personalizing the other side.