WAVEFORM

Log Periodic Outdoor Antenna Pole Mount Instructions

Parts Included





Assembly

1 Attach the L-Bracket to the antenna

Ensure the large washer is between the antenna and the bracket, and the smaller locking washer is between the bolt's head and the L-bracket. Tighten the bolt securely.

2 Position clamps and U-bolts

Slide both U-bolts through the clamp and the L-bracket.



3 Secure with washers and bolts

Place large washer and small locking washer onto each U-bolt, and tighten eavenly across all bolts until the bracket is secure.





4 Done!

