


#	Part Code	QTY	Nm
1	VTCE7A-MD	1	
2	VTCE7A-CS	1	
3	VTCE7A-SS	1	
4	VTCE7A-LK	1	
Flip Chip Kit Kit to replace the head tube and down tube cable guides on all Sommet and Escarpe frames (2021 >).			
5	VTEA-FHNT-L	1	
6	VTEA-FHNT-R	1	
7	VTEA-FHBT-M8X50	1	10Nm
Cable Guide Kit Kit to replace the lower shock bolt and flip chip on all Sommet and Escarpe models (2021 >).			
8	C7B-CGA	2	
9	M4x12L-M	2	3Nm
10	TFYM-DCP	1	
11	TFYM-DCP	1	3Nm
Mount Shock Bolt Kit Kit to replace the top trunnion shock mount bolts and spacers on all Sommet and Escarpe frames (2021 >). Includes bolts and spacers for both sides. No bearings included.			
13	VTEA-FHWS	2	
14	VTEA-LKBT-M10X17	2	
V-Link Pivot Kit Kit to replace the bolts, spacers and threaded element of the seat tube pivot on the suspension linkage on all Sommet and Escarpe frames (2021 >). No bearings included.			
15	NTR-FWS R2	2	
16	NTR-LAX R3	2	14Nm
17	TB-M8-30L	1	
V-Link Seat Stay & Horstlink Kit Kit to replace the bolts, washers and spacers of the seat stay linkage (rear pivots of suspension linkage) or horstlink pivots (back of chainstays) on all Sommet and Escarpe frames (2021 >). These pivots share the same hardware. Each kit includes hardware for 1 set of pivots (no bearings included). 2 kits required to replace all V-Link Seat Stay and Horstlink pivots.			
18	VTEA-LWS-19x15x5	4	
20	VTEA-SAX-26L	4	14Nm
21	ASEE-LWS	8	
22	VTEA-SNT	4	10Nm
23	NTR-BSP R2	1	
Main Pivot Kit Kit to replace the axle and spacers of the main pivot on all Sommet and Escarpe frames (2021 >). No bearings included.			
25	NTR-BWS	2	
26	VTEA-LBT-83.5	1	19Nm
27	AFDC-CWS	1	
28	TCBC-CGR	3	
Frame Bearing Kit Kit to replace the frame bearings on all Sommet and Escarpe frames (2021 >). No hardware included.			
12	6901-2RS	4	
19	6802V-2RS	8	
24	6902-2RS	2	



RECOMMENDED TORQUE VALUE

Shock Bolts	14Nm
V-Link Pivot	14Nm
V-Link Seat Stays	14Nm
Horst Link	14Nm
Main Pivot	19Nm
Hanger	25Nm
Cable Guides	3Nm