

Glass Film Installation Tips

Tools You Need

- Tape Measure
- Ruler
- Squeegee
- Spray Bottle
- Mild Dish Detergent
(for making a wetting solution)
- Utility Knife
- Paper Towel



How to Install



1. Inspect and rewind the film

Inspect the film and rewind in the reverse and then keep it that way. *(For some films, at least a day before using it.)*



2. Making wetting solution

Mix 2~3 drops of clear liquid dishwashing soap into a half-quart of clean water; in a spray bottle/container.



3. Cleaning the window

Spray the window with this wetting solution and thoroughly clean the window of all dirt, dust, grease, etc. Use a squeegee to make the window clean.



4. Cutting the film

Position a utility knife against a ruler or straight edge to cut the film. Cut the film about 1 inch wider than the window pane. You will trim the film to the exact size later.



5. Spray the window

Spray the window evenly with plenty of wetting solution. *(If the room temperature is cold, warm up the room so the glass is warm.)*



6. Separate the film from the backing

Separate the film from the transparent polyester backing. The film is very thin. *(If you have trouble separating it from the backing, place a piece of tape on the corner and gently peel back.)*



7. Attaching the film to the window

Spray the adhesive side of the film evenly with wetting solution, being careful not to wrinkle or crease the film. Now you are ready to attach the film to your window. You will place the film 1/8 inch inside the window and can shift it around to perfect fit. Use the wetting solution, squeegee the film to remove all bubbles, and then trim the excess film with the utility knife. Leave a gap of 1/8 inch between all edges of the film and the window frame. Spray the glass film surface again, and squeegee in the outward directions to remove any remaining bubbles and secure the edge.

Clean the surface with a paper towel, and enjoy!

IMPORTANT

- Please apply the glass film from inside of the room. Do not apply the film outside.
- Please apply the film to flat and smooth surface, glass or mirror only.
- DO NOT apply the film to WIRE GLASS, any CAR GLASS, BULLETPROOF GLASS, VERY OLD GLASS, and ACRYLIC BOARD.
- The glass films can be removed after installation, but reusing of glass films is not recommended.
- Sometimes bubbles appear. These are usually visible from the outside, not from the inside.
- Milky white patches may occur during and after installation of item#01316 - 01319, but these should disappear in 2 days to 1 week.