



# INSTALLATION INSTRUCTIONS

## Thank you for purchasing a PediPull!

Note: These instructions apply to most metal and wood doors. Some door types, such as glass, will require adhesive or through-bolt mounting. If unsure, please contact a qualified tradesperson for assistance.

### Tools needed for installation:

- Drill
- 1/8" Drilling bit
- #2 Roberston (square) bit

### 1. Locate the PediPull on the door and check for clearance.

- a. It should be mounted at the bottom corner of the door, furthest from the hinges, on the side that swings out (the 'pull' side).
- b. Make sure that the PediPull does not interfere with the door frame or other objects.

### 2. Mark and pre-drill 4 pilot holes if necessary.

### 3. Ensure that the included screws are shorter than the thickness of the door.

### 4. Using the drill and bit, install the four screws through the PediPull holes and into the door.

- a. Note that some doors may be hollow in some areas. The PediPull can still be operated if only three screws are able to grip the door.

### 5. Test and enjoy the hands-free operation!

