



Speed DemonTM LIGHTS

Installation Guide for 2003-2007.5 Chevrolet Silverado/Avalanche Fog Light Kit (10-30130)

Parts Included

2 Light Brackets

Tools Required

Miscellaneous Hand Tools

PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE INSTALLATION.

- Application models vary, we recommend to verify fitment before beginning installation process.
- Images featured in the instruction documents may not always exactly match your model or part.

STEP 1

Preassemble the U-shaped Brackets to the LED Pod Lights.

Use our step by step guide to help you put the LED pod lamps together with the U-brackets.



STEP 2

Mount the Metal Bracket Plate to the Twin LED Pod Lights.

Run the bolts upwards from below the U-bracket so you have an easier time securing the connection with nuts.

Please note that the metal bracket plate you see in these pictures are from a test fit and will not be in the color you will get in your package. Your metal bracket plate will be colored for aesthetics.





Speed DemonTM LIGHTS

Installation Guide for 2003-2007.5 Chevrolet Silverado/Avalanche Fog Light Kit (10-30130)

STEP 3

Remove the Stock Bezel and Fog Lamp.

Use a 10mm wrench to unfasten the screws securing the stock plastic bezel. Disconnect the stock harness from the factory fog lights. Remove the factory fog lights as well as the stock plastic bezel.

As you can see, the metal bracket plate has similar dimensions to the plastic bezel which makes for simple, direct replacement.



STEP 4

Mount the LED Pod Lamp Assembly.

Adjust the angles of the twin LED pod lamps to ensure they shine through the gap.





Speed DemonTM LIGHTS

Installation Guide for 2003-2007.5 Chevrolet Silverado/Avalanche Fog Light Kit (10-30130)

STEP 5

Connect the Wires to the Stock Harness using Speed Demon part #10-30250.

Repeat steps 1-5 for the other side.



STEP 6

Test the LED Pod Lights to Make Sure They Light Up.

Once they do, you can now enjoy your Chevy Avalanche or Silverado's brand new LED pod lights!

