



# Speed Demon<sup>™</sup> LIGHTS

## Installation Guide for 2011-2015 Ford Super Duty 20" Dual Row Bumper Mount (10-30146)

### Parts Included

1 Bumper Mount

### Tools Required

Miscellaneous Hand Tools

### **PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE INSTALLATION.**

- Application models vary, we recommend to verify fitment before beginning installation process.
- Images featured in the instruction documents may not always exactly match your model or part.

## **STEP 1**

Install light bracket in opening of front bumper. Bolt bracket to upper rear holes of bumper.  
Hand tighten.

See Figures 1 & 2.



Figure 1



Figure 2

## **STEP 2**

Place 1/2" bolts through bracket and bumper flange. Tighten using 3/4" wrench. (Use a 1/2" washer on bottom of bracket and top of flange).

See Figure 3.



Figure 3



# Speed Demon<sup>TM</sup> LIGHTS

## Installation Guide for 2011-15 Ford Super Duty 20” Dual Row Bumper Mount (10-30146)

### STEP 3

Tighten rear Allen bolts using 3/16” Allen and 1/2” wrench.

See Figure 4.



Figure 4

### STEP 4

Insert light in bumper opening and place in bracket.

See Figure 5.



Figure 5

### STEP 5

Set desired light angle and tighten 8mm bolts.

See Figure 6.



Figure 6

### STEP 6

Wire light bar using Speed Demon wiring harness (10-30030).