



Speed Demon[™] LIGHTS

Installation Guide for 2003-2009 Dodge Ram 20" Dual Row Bumper Mount (10-30147)

Parts Included

2 Light Brackets

Tools Required

Miscellaneous Hand Tools

PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE INSTALLATION.

- Application models vary, we recommend to verify fitment before beginning installation process.
- Images featured in the instruction documents may not always exactly match your model or part.

STEP 1

Remove factory hardware and tow hooks and set aside.



STEP 2

Align brackets to existing holes.

STEP 3

Reinstall tow hooks over brackets with factory hardware finger-tight, with brackets shifted towards the outside of the truck to allow room for the light install.

STEP 4

Install the 20" light bar on the brackets and finger-tighten. Adjust the light angle, then finish tightening.

STEP 5

Adjust light position by shifting brackets, then finish tightening mounting bracket.

STEP 6

Connect 20" light bar using Speed Demon wiring harness part #10-30030.