



# Speed Demon<sup>™</sup> LIGHTS

## Installation guide for Dodge Ram 2500/3500 2003-2019 Bumper Mount (10-30240)

### STEP 1

Remove factory hardware and tow hooks and set aside.



### STEP 2

Align brackets to existing holes.

### STEP 3

Reinstall tow hooks over brackets with factory hardware finger-tight, with brackets shifted towards the outside of the truck to allow room for the light install.

### STEP 4

Install the 20" light bar on the brackets and finger-tighten. Adjust the light angle, then finish tightening.

### STEP 5

Adjust light position by shifting brackets, then finish tightening mounting bracket.

### STEP 6

Connect 20" light bar wiring harness.