

# INSTRUCTIONS

**FITS: 2017- 2018 Polaris Axys  
BD Turbo Kits**



# ***Contents List***

- (1) 8mmx20mm SS Allen Head Bolt
- (1) M8-1.25x20mm Bolt
- (1) 5/16-18x3/4 Bolt
- (1) Turbo Hold Down Bracket
- (1) Turbo Index Bracket

# ***Initial Teardown***



Remove Hood and side panels

# ***Initial Teardown***



Remove the pipe hold down spring

# ***Initial Teardown***



Remove the Air Intake Tube from the air box

# ***Initial Teardown***



Remove cold air intake tube from the turbocharger

# ***Initial Teardown***



Remove the springs that hold the muffler to the turbo exhaust outlet

# ***Initial Teardown***



Remove the muffler from the sled.



# ***Initial Teardown***



Remove this bolt from the exhaust side of the turbo

# *Initial TearDown*



(1)Remove this bolt from the intake side of the turbo (2)Remove the outside bolt from the block off plate.

# ***Install Bracket***



(1)Place the bracket in the turbo assembly with the provided metric bolt Labeled JH 8.8, in the tab that goes to the block off plate. (2) install the other provided bolt into the intake side of the plate and turbo. (if your having alignment issues grab the exhaust inlet pipe and intake tube and twist the proper direction to align the holes)

# ***Install Bracket***



Re use the bolt on the exhaust side and tighten all 3 of the bolts

# ***Install Bracket***



There will be Two left over bolts not needed for the kit

# ***Install Bracket***



Make sure that the front of the turbo bracket is butted up with the tab on the chassis

# ***Install Bracket***



Turbo Hold Down Assembly

# ***Install Bracket***



Put the bracket in place making sure that the top tab is latched on top of the Turbo Mounting Bracket. Install the Hex head bolt into the existing threaded hole on the Chassis. Tighten ensuring the Hold Down bracket is holding the Mounting bracket tight against the chassis.



# ***Install Muffler***



Re Install your muffler. Its easiest to put the tunnel dump side of the muffler in place, then using one hand pull on the exhaust inlet pipe towards the front of the vehicle and slide the muffler in place from the bottom up.

# ***Finish Re Install***



Re Install the springs on the muffler and pipe. Install  
Cold Air Intake Tube and tighten all hose clamps.  
And your New Turbo Lock down kit is installed.  
Go For a Rip and Enjoy