



De-Lite Install Instructions



Contents List

- 1 Boondocker De-Lite

Tool List

- T 25 torques
- 8mm socket/ratchet

Boondocker LLC
2085 heyrend Way
Idaho Falls, ID 83402
208-542-4411



De-Lite Install Instructions



1. Remove the wind deflector from the hood by pulling the deflector away from the hood until the 3 panel clips release from the rubber grommets.

Note: 23+ snowmobiles do not have a center rubber grommet.



2. Unplug the headlight.



3. Using an 8mm socket, remove the 3 bolts holding the headlight in place.



4. Remove the headlight from the hood.



De-Lite Install Instructions



5. Using a t 25 torques remove both left and right ear plastics located at the back of the headlight hole.



6. Using a t 25 torques Loosen the four gold bolts holding the top of the storage box to the hood.



7. Starting on the left side of the hood, Bolt the previously removed ear to the hood mounting the De-Lite between the ear and the hood.

Note: the De-Lite should slide just under the top storage box edge.



8. Using light pressure push the bottom of the De-Lite into the headlight hole until the edge flange slides under the hole to lock in place.



De-Lite Install Instructions



9. On the Right side of the hood, Bolt the previously removed ear to the hood mounting the De-Lite between the ear and the hood.

Note: the De-Lite should slide just under the top storage box edge.



10. Using light pressure push the bottom of the De-Lite into the headlight hole until the edge flange slides under the hole to lock in place.



11. Using a t 25 torques Tighten the four gold bolts holding the top of the storage box to the hood.



12. Reinstall your wind deflector to the hood by pushing each panel clip into the rubber grommets starting from the center moving out.