



BoonDocker

PERFORMANCE

KTM Control Box Installation Instructions



BoonDocker KTM Control Box



1. Route harness through handlebars and along stock wire harness. Mount control box to the handle bars.



2. Air temp adaptor plugs to the intercooler mounted air temp sensor



3. The Wastegate solenoid connector plugs into the boost solenoid and has a Violet/white and Red wire.



4. Install EFI connectors between the injector and the factory injector harness.
Note: this connection is hard to get to without taking off the throttle bodies.



5. Install BoonDocker TPS harness between the Throttle Position Sensor and the factory harness.



6. Route green wire above stock wire harness under the frame to the spark plug wire. Wrap around 10 times. Cut off excess wire.

Revised 1/24/2014

BoonDocker KTM Control Box



7. Wrap green wire & wrap tightly with electrical tape.



8. Route black ground to the stock ground bolt. Or the battery ground if you have a battery.



9. Boost line routes with boost solenoid adaptor and hooks into the "push to connect" on the intercooler.



10. The Auxiliary injector connector is similar to the solenoid connector. It is shorter and has a Violet and Red wire.