

# Vents



Remove side panels and hood.

# Vents



Optional:  
Remove stock vents, this is not required but greatly improves air flow.

# Vents



Push BoonDocker deep snow vent onto factory air intake box insuring the locking tab is slid into its' notch and the vent sits tightly around every edge.

# Vents



Screw vents to factory air intake box with provided black phillips screws.