


Intercooled Model Only



According to supplied instructions mark and measure out the intercooler cut-out.

Intercooled Model Only




Using a 3/8" drill bit make holes in corners of marks to accommodate air saw blade. Be sure to stay INSIDE your marks.

Intercooled Model Only




Using an air saw, or preferred cutting method, cut out the marked area staying inside the lines. Make sure you don't go too deep into engine bay to avoid damage. We used a very short blade to do this.

Intercooled Model Only



Clean up edges with a deburring tool and prepare to install the cooler.

Intercooled Model Only



Install hoses as shown through to front of engine cavity along the outside edges of the bulk head.

Intercooled Model Only



Route MAG side hose (A) up along existing coolant line (B)

Intercooled Model Only



Continue to route hose between ECU and blue fuel line.

Intercooled Model Only




Route PTO side coolant line up to the front cross member to the coolant bottle.

Intercooled Model Only



Follow this routing, be sure to keep away from Y-pipe

Intercooled Model Only



Be sure and zip tie coolant in place on cross member.


Intercooled Model Only




Intercooled Model Only




Intercooled Model Only



Intercooled Model Only



Intercooled Model Only



Intercooled Model Only

