

# FRENERGY

## Magnafix Directions of Use

### i. METAL TO NON-METAL SURFACE

*For applications when applied to one metal (iron) surface and one non-metal surface (plastic, wood, aluminium, paper, etc.)*

1. Clean surface of all dirt and foreign matter.
2. Wipe clean with alcohol (especially new surfaces)
3. Cut required length, peel off adhesive cover and apply to non-metal surface.
4. Press firmly along entire length of tape so adhesive bonds well.
5. Ready to use!


### ii. TWO NON-MAGNETIC SURFACES

*For applications where A and B Magnafix is required (ie. both surfaces are non-magnetic, such as plastic, wood, aluminium, paper, etc.)*

1. Clean surface of all dirt and foreign matter, wipe clean with alcohol (especially new surfaces).
2. Cut required length (area). Peel off adhesive cover and apply to non-metal surface (fixed solid area is better to start with) eg. framework, building windows.
3. Press firmly along the entire length of tape, so the adhesive bonds well.
4. Cut required length the same as the applied tape on surface already covered with opposite pole (A or B).
5. Apply magnetic side to surface of tape already applied (adhesive side will now be face up).
6. Peel off adhesive cover from tape.
7. Apply panel, sheet, or item being used on to adhesive.
8. Press very firmly along entire area of adhesive tape and item sheet.
9. Allow 5-10 minutes to bond.
10. Remove item.
11. Press firmly along length of tape on second application to ensure a strong bond.
12. Reapply to position.



**PART A**



groove

**PART B**