



FOR SOLID LATCHLESS DOORS

INSTRUCTIONS

- 1.** Measure and mark level hole locations.
- 2.** Drill holes - For all metal and wood doors, use a smaller drill bit for a pilot hole and drill perpendicular to the floor, remove all burrs.
- 3.** Add a few drops of thread glue and tighten bolts. Use 25mm/0.98" bolts for doors 25-45mm/0.98-1.77" thick doors. Use 40mm/1.57" bolt for thicker doors and tighten.
- 4.** Check interference with objects on full open and close motions.
- 5.** Adjust door closer resistance so it is easy to open the door with your foot.
- 6.** Add sticker above the door handle and near basin/hand dryer.
- 7.** Add Latch Blocker to door frame if needed.

