

BF4KIT1 – Configuration Guide

Tools Required

- Drill
- 27mm hole saw
- Measuring tape (or ruler)

Instructions

1. Lay out four bases, as shown in the technical drawing.
2. Beginning with “Base A”, standing at one of the longer (1660mm) sides, measure on the inside, from the right hand side, 495mm from the inside edge, and 42mm up from the base, and then mark it for drilling.
3. Then turn to the perpendicular shorter (1260mm) side on your right. On this side, measure on the inside - from the right hand side - 406mm from the inside edge, and 42mm up from the base, and then mark it for drilling.
4. Moving to “Base B”, again standing at one of the longer (1660mm) sides, measure on the inside, from the left hand side, 495mm from the inside edge, and then 42mm up from the base, and then mark it for drilling.
5. Then turn to the perpendicular shorter (1260mm) side on your left. On this side, measure on the inside, from the right hand side, 406mm from the inside edge, and 42mm up from the base, and then mark it for drilling.
6. For “Base C”, repeat the steps 4 and 5 on this guide on “Base C”.
7. For “Base D”, repeat steps 2 and 3 on this guide on “Base D”.
8. Now they are all marked, drill the holes, using the 27mm hole saw.

