

ASSEMBLY INSTRUCTION FOR SE 590A-106-675

1. POSITION TANK ONTO TROLLEY
2. CONNECT RATCHET STRAP AROUND TANK
3. TIGHTEN RATCHET STRAP UNTIL TANK IS SECURE
4. SECURE LOOSE END OF STRAP



5. ROTATE EYEWASH 90°
6. CONNECT EYEWASH BRACKET TO TANK
7. TIGHTEN BOLTS TO SECURE EYEWASH TO TANK
8. CONNECT SUPPLY TO EYEWASH STEM



ASSEMBLY INSTRUCTION FOR SE 590A-106-675

9. ALIGN BODY SPRAY
TO FRONT OF TANK

10. WRAP TEFLON TAPE
AROUND THREADS

11. HOLD VALVE WITH
SPANNER AND TIGHTEN
SHOWER ROD FIRMLY
WITH HAND

