


Leather AXE Cover



POPOV LEATHER
HANDMADE SINCE 2013

- Print 1 copy in Portrait 100% scale
- Use this ruler to check for proper measurement



- Glue on to cardboard and carefully cut out the pattern. Use a sharp tool to mark shapes and hole placements.
- This project is completed using 12.7mm line snaps and 9.2mm double cap end rivets.
- Use a 3mm punch to punch out holes.
- Follow the video for assembly instructions.

*If you're wanting to build a custom shape, to fit your axe trace your axe head with a folded piece of paper. Align the fold with the bottom edge of the axe. Add 12mm to the blade edge for the rivets. Add 6mm to the top edge for leather thickness allowance. Cut out rough shape and use our template to estimate the hole spacing and tab.

