

DCCSUPPLY.COM SALES@DCCSUPPLY.COM 847-266-1220

PAX S80 & A80 Protective Spill Cover - Installation Instructions

You have made a great choice to protect your device from germs, spills and grime while extending the life of your terminal.

- 1. DO NOT REMOVE THE WHITE MYLAR STRIPS YET.
- 2. Place the cover on the device, making sure the keypad portion of the cover is lined up with the keys properly.
- 3. Keeping the cover in place with one hand, remove the FRONT white Mylar strip with the other hand. Secure the FRONT tape down.
- *If the tape comes off with the white strip, simply reapply the tape to the cover and carefully separate the tape from the white Mylar.
- 4. Secure the RIGHT side next by removing the white strip. Adhere the strip working from the bottom to the top.
- 5. Next, remove the LEFT white strip. Moving from the bottom right to the top adhere the tape. When you get near the top, then remove the TOP tape and adhere. Check and smooth down any bubbles before pressing down the TOP tape. However, you can safely lift up the edge to stretch and reapply the cover.

Tips for Care and Use

- This cover is durable but it is made of plastic, so treat it gently.
- Do not use sharp objects or pens as they may puncture the cover.
- Clean with a damp cloth or antibacterial wipe.
- Do not remove the cover to clean it.