

DCCSUPPLY.COM SALES@DCCSUPPLY.COM 847-266-1220

Pax Q30 Keypad Protective Spill Cover Installation Instructions

You have made a great choice to protect your device from germs, spills and grime while extending the life of your Terminal/PIN Pad!

- 1. Clean the keypad area so that it is free of dust and grime.
- 2. Place the cover over the keypad, being careful to align the keypad properly over the keys.
- 3. Remove the FRONT mylar only, and adhere just the FRONT tape.
- *If the tape comes off with the white strip, simply reapply the tape to the cover and carefully separate the tape from the white mylar.
- 4. Remove the LEFT, RIGHT, and BACK mylar and adhere.

Final Step: Smooth down all edges of the cover.

Tips for Care and Use

- This cover is durable, but it is made of plastic, so treat it gently.
- Do not use sharp objects or pens as they may puncture the cover.
- Clean with a damp cloth or antibacterial wipe.
- Do not remove the cover to clean it.