



Designed to offer all of the advantages of our standard tilt and swivel unit but with the addition of a unique and innovative key locking function. Incorporating a quick release 3mm thick mild steel locking arm, this unit offers un-rivalled security, build quality and ease of use.

Features

- Manufactured in robust mild steel
- Durable powder coated finish
- Quick release mild steel locking arm
- Simple to use push lock design
- Smooth 60° tilt and 190° swivel action
- Dual cable entry options
- Flange cover to conceal fixing holes
- Screw or adhesive pad fixing options (screws provided)
- Supplied fully built for a simple install
- Upgradeable in the field with a simple top plate swap

Options

- Available keyed alike, keyed to differ and with or without master key facility
- Bespoke design service for special requirements
- Available in a wall mount version
- Different height poles

TO SUIT VERIFONE VX805

Installation instructions

1. Select the desired position for your payment terminal.
2. Place the terminal stand on the countertop and choose whether the unit is best swivelling clockwise or anti-clockwise.
3. Position the base plate so that sufficient access can be gained to the terminal by both the customer and vendor when the unit is swivelled through it's 190°.
4. With a pencil or felt pen, mark through each hole onto the countertop.
5. If using the screws provided, drill a 2mm pilot hole in the countertop to accept the fixing screws. Please note that these screws are intended for use when fixing to a wood countertop, other fasteners may be required when fixing to different types of countertop material. If using the self adhesive pad fixing method, refer to the separate instruction sheet for use.
6. If the cables are to be fed through the bottom of the base pole then drill a large hole in the countertop to accept them. This is not necessary if the countertop cable entry is to be used.
7. With the power switched off, feed the cables through the desired base pole entry and up through the top exit of the pole. Ensure that sufficient cable length is fed through the top of the pole to allow connection to the terminal.
8. Screw the Terminal stand down to the countertop.
9. Connect the cables to the payment terminal.

10. Push the payment terminal into the cradle plate ensuring that the back is lined up as per the picture. Ensure the terminal is pushed down until all of the rubber feet touch the cradle plate.
11. Engage the lock arm and push the lock in to secure the terminal
12. Switch on the terminal power supply.

NAME: _____	DATE: _____
ADDRESS: _____	

LOCK NUMBER (Found on key): _____	
PLEASE FILL IN AND KEEP THIS SHEET SECURE IN THE EVENT OF KEY LOSS	

1530 Old Skokie Rd
Highland Park
Illinois
60035

Tel: 877 298 6939