

INSTALLATION INSTRUCTIONS

2" SIDEBAR FOR VW CADDY 04+ SWB

PARTS LIST:

No.	Qty	Part Description	No.	Qty	Part Description
1	2	Left/Right Sidebar	7	2	M8 X 40mm T-Bolt
2	2	Bracket A	8	2	M8 X 35mm Bolt
3	2	Bracket B	9	8	8mm Flat Washer
4	4	M10×40mm Bolt	10	8	8mm Spring Washer
5	4	10mm Flat Washer	11	6	M8 Hex Nuts
6	4	10mm Spring Washer	12	2	8mm Plastic Washer

1

INSTALLATION PROCEDURE

1. Starting the installation from telling all the Right and Left brackets firstly, and put them on according position.
2. Install the Right/Passenger Bracket A (Fig1),find out the install hole, put the M8×40mm T-Bolt is placed into the hole, and using M8×35mm Bolt 、 8mm Flat Washers、 8mm Spring Washers、 M8 Hex Nuts and 8mm Plastic Washer , M10×40mm Bolt、 10mm Flat Washers、 10mm Spring Washers、 to tighten the Right /Passenger Front Bracket on the vehicle , but do not tighten hardware.
3. Install the Right/Passenger Bracket B (Fig1),find out the install hole, put the U type bolt (13) is placed into the hole, and using、 8mm Flat Washers、 8mm Spring Washers、 M8 Hex Nuts and 8mm Plastic Washer , M10×40mm Bolt、 10mm Flat Washers、 10mm Spring Washers、 to to tighten the Right /Passenger Rear Bracket on the vehicle , but do not tighten hardware.
4. Check the Sidebar for level and adjust as necessary. Tighten all hardware at this time.
5. Repeat same steps 1-4for Left /Driver Bracket Sidebar installation.

To protect your investment, wax this product after installing. Regular waxing is recommended to add a protective layer over the finish. Do not use any type of polish or wax that may contain abrasives that could damage the finish.

For stainless steel: Aluminum polish may be used to polish small scratches and scuffs on the finish. Mild soap may be used also to clean the Sidebar.

For gloss black finishes: Mild soap may be used to clean Sidebar.

Passenger Side Installation Pictured

Figure 1

