

TRIPOD STAND ASSEMBLY INSTRUCTIONS

INCLUDED IN PACKAGE (7PCS):

- TRIPOD LEGS X 1
- EXTENSION/BOOM ARM X 1
- MOBILE PHONE MOUNT X 2
- BALL HEAD + SCREW X 2
- SANDBAG X 1

PARTS:



BOOM ARM TRIPOD LEGS



SANDBAG

STEP 1: Set up tripod legs

Pull the legs outward and adjust to your desired base height. Tighten knob to secure height in place.



STEP 2: Adjust middle pole height

Once the base height is set up as desired, adjust the pole in the middle section by pulling it upward. Tighten knob to secure in place.



STEP 3: Disassemble boom arm

Disassemble by unscrewing the knob to the left and removing two of the loose circular parts. Then, adjust top part of stand to your desired height.



STEP 4: Attach arm to tripod stand

Take the circular part with the indent and attach to the top part of the stand in desired location. Take the other flat circle and place it on top to cover the pole, then place boom arm alongside. To attach, tighten with the knob.



STEP 5: Attach ball head to boom arm

Take the ball head and attach to the tip of the arm extension.



STEP 6: Attach mobile phone mount

Next, attach the mobile phone holder. It can attach in portrait or landscape. Use the loose screw and attach to ball head to secure position. Finally, fill sandbag to prevent stand from moving.



TRIPOD STAND ASSEMBLY INSTRUCTIONS

INCLUDED IN PACKAGE (7PCS):

- TRIPOD LEGS X 1
- EXTENSION/BOOM ARM X 1
- MOBILE PHONE MOUNT X 2
- BALL HEAD + SCREW X 2
- SANDBAG X 1

PARTS:



BOOM ARM TRIPOD LEGS

MOBILE PHONE
MOUNT X 2



SANDBAG

FINAL SET UP: Portrait



FINAL SET UP: Landscape

