

VW up!/Skoda Citigo/Seat Mii Mirror Anti-Fog Film Kit

Instructions

1. Clean the mirror glass thoroughly with the provided wet and dry wipes.
2. Wet the mirror glass.
3. Peel off the protective film Number 1 and apply the adhesive face of the anti-fog film to the glass using the wet surface to correctly align the film to the glass.
4. Use the provided squeegee to remove excess water and any air or liquid bubbles under the film.
5. Leave the film for an hour to allow any remaining water to evaporate before removing the outer protective film Number 2 film.
6. Repeat on the other side.